AULYX
AX-TYWFDORALOC
Door -Alarm

Sound and light alarm
- Flashlight
- 100 decibel

tuya

Timed arming and disarming

Various functions can be adjusted arbitrarily

Try to adjust these functions, can be adjusted according to your needs.

Remotely receive alarm information

View alarm records

①

Sound and light door and window alarm won't manual

②

③

④

⑤

APP Operation

A. Arm (turn off monitoring).

B. Disarm (turn off monitoring).

⑥

3. Click Set to set the time for automatic closing/opening and alarm.

4. Timer arm and disarm, click "Add".

⑦

6. Modify Device Name/Shared

1) Click on the upper right corner.

⑧

4. Click Share Device to add a share.

5. Click to share

⑨

Installation

1. Use the battery installation.

2. Installation Precautions.

3. Fill glass bead installation method.

Take out the glass beads in the bag, insert the door and window body and the magnetic sticker as shown in Figure 1, and fill the glass beads.

Tear off the release paper on the back of the receiver and the magnetic sticker and stick it on the door and window body as shown in Figure 2.

⑩

Installation precautions

1. Try ON/OFF distance between the remote and the device.

Maintenance

1. Replacement battery.

Technical Parameter

Working voltage: DC3V
Standby current: ≤100uA
Alarm current: ≤70mA
Alarm sound pressure: ≥100dB(A)
Wireless frequency: 2.4G(2.4GHz)
WiFi standard: IEEE 802.11 b/g/n 2.4hz